

Algal Toxin Strip Test (Microcystins) Recreational Water


1. Collect Sample




Collect 1 to 2 mL of sample.

2. Transfer/QuikLyse™ *

Using the graduated pipette provided, transfer 1 mL of SAMPLE to the lysis vial containing the dried lysis reagent.




*Patent Pending




3. Add Reagent Paper/QuikLyse™ *

Using the forceps provided, add 1 reagent paper to the lysis vial.




4. Transfer

Using the pipette provided, add 7 drops of SAMPLE to the conical, flip-top tube.



(The conical, flip-top tube contains dried reagents.)

5. Shake and incubate



Close the conical, flip-top tube and shake for 30 seconds.



(Dried reagents will dissolve, turning the sample purple.)

6. Test

Insert test strip into conical, flip-top tube with arrow pointing down. (sample pad down).



Incubate for 10 minutes.




7. Dry

Remove test strip. Lay flat and allow to continue developing for 5 minutes.



8. Interpret



INTERPRET TEST

CONTROL LINE	TEST LINE	INTERPRETATION
NO CONTROL LINE PRESENT	NO TEST LINE PRESENT	INVALID RESULT
CONTROL LINE PRESENT	NO TEST LINE PRESENT	>10 ppb
CONTROL LINE PRESENT	MODERATE INTENSITY TEST LINE PRESENT	BETWEEN 0 AND 10 ppb

For Ordering or Technical Assistance Contact:

ABRAXIS, LLC 54 Steamwhistle Drive, Warminster, PA 18974 Phone: 215-357-3911 Fax: 215-357-5232 www.abraxiskits.com